

Oil Pan Replacement

Removal Procedure


Caution: Refer to [Battery Disconnect Caution](#) in the Preface section.

1. Disconnect the battery ground cable. Refer to [Battery Negative Cable Disconnection and Connection](#).


Caution: Refer to [Safety Glasses Caution](#) in the Preface section.

Caution: Refer to [Vehicle Lifting Caution](#) in the Preface section.


2. Raise and support the vehicle. Refer to [Lifting and Jacking the Vehicle](#).
3. Remove the air deflector. Refer to [Front Air Deflector Replacement](#).
4. Drain the engine oil and remove the oil filter. Refer to [Engine Oil and Oil Filter Replacement](#).
5. Remove the engine splash shield. Refer to [Engine Splash Shield Replacement](#).
6. Remove the starter motor. Refer to [Starter Motor Replacement](#).



7. Remove the left side close out cover to cylinder block retaining bolt (2).
8. Remove the left side close out cover (1).



9. Remove the right side close out cover to cylinder block retaining bolt (2).
10. Remove the right side close out cover (1).



Important: Observing the orientation of the intermediate steering shaft (1) with reference to the pinion shaft (3) will minimise the potential of incorrect steering column assembly alignment.

11. Mark the intermediate steering shaft (1) in relation to the pinion shaft (3).


Important: Bolts with micro-encapsulated thread sealant must be discarded after removal.

Important: Make sure the bolt hole is thoroughly cleaned and all micro-encapsulated thread sealant is removed.


12. Remove the intermediate steering shaft to pinion shaft retaining bolt (2).

Discard the bolt.


13. Disconnect the intermediate shaft (2) from the pinion shaft (3).




14. Remove the steering gear to subframe retaining bolts (1).
15. Slide the steering gear forward to gain full access to the sump.




16. Disconnect the oil level/temperature sensor electrical connector (1) from the oil level/temperature sensor.



17. Remove the transmission to oil pan retaining bolts (1).



18. Remove the oil pan to front cover retaining bolts (1).
19. Remove the oil pan to cylinder block front retaining bolts (2).
20. Lower the vehicle.



21. Position the [J 41798](#) (1) on the cylinder head (3).

Notice: Refer to [Fastener Notice](#) in the Preface section.


22. Install the [J 41798](#) to cylinder head retaining bolts (2).

Tighten

Tighten the bolts to 50 N·m (36 lb ft).


Important: When lifting the engine assembly, observe the clearance between the rear of the engine assembly and the dash panel.

23. Install [J 41803](#) and [J 28467-B](#) and raise the engine assembly 20mm.
24. Raise and support the vehicle. Refer to [Lifting and Jacking the Vehicle](#).






25. Remove the lower engine mount to crossmember retaining nut (1) from both engine mounts.
26. Lower the vehicle.



27. Remove the oil pan to engine rear cover retaining bolts (2).
28. Remove the oil pan to cylinder block retaining bolts (1).
29. Remove the oil pan (3).



Important: DO NOT allow foreign material to enter the oil passages of the oil pan, cap, or cover the openings, as required.

Important: Take care not to gouge, score, or damage the oil pan sealing surface.

30. Drill out the retaining rivets (3) from the oil pan, if required.

Important: The oil pan gasket and rivets are single use only components and must be replaced whenever the oil pan is removed from the cylinder block.

31. Remove the oil pan gasket (1) from the oil pan (2).

Discard the gasket and rivets.


32. Clean and inspect the oil pan as necessary. Refer to [Oil Pan Cleaning and Inspection](#).
33. Clean the base of the engine block. Refer to [Replacing Engine Gaskets](#).

Installation Procedure


Important: The alignment of the structural oil pan is critical. The rear bolt hole locations of the oil pan provide mounting points for the transmission housing. To ensure the rigidity of the powertrain and correct transmission alignment, it is important that the rear of the block and the rear of the oil pan are flush. The rear of the oil pan must NEVER protrude beyond the engine block and transmission housing plane.

Important: The original oil pan gasket is retained and aligned to the oil pan by rivets. When installing a new gasket, it is not necessary to install new oil pan gasket rivets.


It is not necessary to rivet the NEW gasket to the oil pan.



1. Apply a five mm (0.2 in) bead of sealant 20 mm (0.8 in) long to the engine block (1). Apply the sealant directly onto the tabs of the front cover gasket that protrude into the oil pan surface. Refer to [Adhesives, Fluids, Lubricants, and Sealers](#).




2. Apply a five mm (0.2 in) bead of sealant 20 mm (0.8 in) long to the engine block (1). Apply the sealant directly onto the tabs of the rear cover gasket that protrude into the oil pan surface. Refer to [Adhesives, Fluids, Lubricants, and Sealers](#).




Important: Make sure to align the oil gallery passages in the oil pan and engine block correctly, with the oil pan gasket.

3. Preassemble the oil pan gasket (2) to the oil pan (3).
 - 3.1. Install the oil pan gasket (2) to the oil pan (3).
 - 3.2. Install the oil pan retaining bolts (1) to the oil pan (3) and through the oil pan gasket (2).



4. Install the oil pan assembly (3).
5. Install the oil pan to cylinder block retaining bolts (1) finger tight. Do not over tighten.
6. Install the oil pan to engine rear cover retaining bolts (2) finger tight. Do not over tighten.
7. Lower the vehicle.
8. Lower the engine to engage the engine mounts to the front subframe.



9. Raise the vehicle.


Notice: Refer to [Fastener Notice](#) in the Preface section.

10. Install the lower engine mount to front subframe retaining nuts (1) on both engine mounts.


Tighten

Tighten the nut to 80 N·m (59 lb ft).

11. Lower the vehicle.
12. Remove [J 41803](#) and [J 28467-B](#) from the engine.



13. Remove the [J 41798](#) (1) from the cylinder head (2).




14. Install the oil pan to front cover retaining bolts (1) finger tight. Do not over tighten.
15. Install the oil pan to cylinder block retaining bolts (2) finger tight. Do not over tighten.
16. Place a straight edge across the rear of the engine block and the rear of the oil pan at the transmission housing mounting surfaces.
17. Align the oil pan until the rear of engine block and the rear of oil pan are flush or even.
18. Measure the oil pan-to-engine block alignment.
 - 18.1. Place a straight edge across the rear of the engine block and rear of the oil pan at the transmission housing mounting surfaces.

Important: The rear of the oil pan must NEVER protrude beyond the engine block

and transmission housing mounting surfaces.

- 18.2. Insert a feeler gauge between the straight edge and the oil pan transmission housing mounting surface and check to make sure that there is no more than a 0.25 mm (0.01 in) gap between the pan and the straight edge.
- 18.3. If the oil pan alignment is not within specifications, remove the oil pan and repeat procedures 17 through to 19.

Notice: Refer to [Fastener Notice](#) in the Preface section.



19. Tighten the M8 oil pan to cylinder block retaining bolts (1).


Tighten

Tighten the bolt to 25 N·m (18 lb ft).

20. Tighten the M6 oil pan to engine rear oil seal housing retaining bolts (2).

Tighten

Tighten the bolt to 12 N·m (106 lb in).



21. Tighten the oil pan to cylinder block retaining bolts (2).

Tighten


Tighten the bolt to 25 N·m (18 lb ft).

22. Tighten the oil pan to front cover retaining bolts (1).

Tighten

Tighten the bolt to 25 N·m (18 lb ft).


23. Position the steering gear in the correct location.



24. Install the steering gear to subframe retaining bolts (1).

Tighten

Tighten the bolts to 65 N·m (48 lb ft).




Important: The intermediate steering shaft and pinion shaft splines must be installed in the position recorded during removal and aligned with the marks previously made.

25. Connect the intermediate steering shaft (1) to the pinion shaft (3).
26. Install the intermediate steering shaft to pinion shaft NEW retaining bolt (2).

Tighten

Tighten the bolt to 25 N·m (18 lb ft).






27. Install the right side close out cover (1).
28. Install the right side close out cover to cylinder block retaining bolt (2).

Tighten


Tighten the bolt to 12 N·m (106 lb in).



29. Install the left side close out cover (1).
30. Install the left side close out cover to cylinder block retaining bolt (2).

Tighten

Tighten the bolt to 12 N·m (106 lb in).



31. Connect the oil level/temperature sensor electrical connector (1) to the oil level/temperature sensor.
32. Install the starter motor. Refer to [Starter Motor Replacement](#).
33. Install the air deflector. Refer to [Front Air Deflector Replacement](#).
34. Install the engine splash shield. Refer to [Engine Splash Shield Replacement](#).
35. Lower the vehicle to the ground
36. Connect the battery ground cable. Refer to [Battery Negative Cable Disconnection and Connection](#).
37. Replace the engine oil and oil filter. Refer to [Engine Oil and Oil Filter Replacement](#).