SECTION 6C1-2A

DIAGNOSTIC CHARTS - V6 ENGINE

CONTENTS

NOTE: For VS Series II LWB vehicles refer to Section 6C1-2A DIAGNOSTIC CHARTS V6 SUPERCHARGED ENGINE in Volume 9 (VS SERIES II LWB AND UPDATE INFORMATION), of the VS Service Manual Supplement.

CAUTION:

Subject		Subject	
1.	System Component Locations	DTC 22	V6 PCM - Throttle Position (TP) (Signal Voltage Low)
2.	PCM Wiring Diagrams		
3.	Powertrain Control Module Connector Identification	DTC 23	V6 PCM - Intake Air Temperature (IAT) (Signal Voltage High)
4.	PCM Connector Voltages with Explanations	DTC 24	V6 PCM - No Vehicle Speed Signal (Automatic Transmission)
5.	Tech 1 Scan Engine Data	DTC 25	V6 PCM - Intake Air Temperature (IAT) (Signal Voltage Low)
6.	Tech 1 Scan Engine Data Descriptions		
7.	Tech 1 Scan Transmission Data	DTC 26	V6 PCM - Intake Air Temperature (IAT) (Signal Voltage Unstable)
8.	Tech 1 Scan Transmission Data Descriptions	DTC 28	V6 PCM - Transmission Fluid Pressure Switch Assembly (PSA) Circuit Fault
9.	PCM Engine Diagnostic Trouble Codes		
10.	PCM Transmission Diagnostic Trouble Codes	DTC 31	V6 PCM - Theft Deterrent Signal Missing
		DTC 32	V6 PCM - Mass Air Flow (MAF) Out of Range
11.	4L60E Transmission Fluid Checking Procedure	DTC 35	V6 PCM - Idle Speed Error
Chart A	On Board Diagnostic System Check	DTC 41	V6 PCM - Ignition Electronic Spark Timi (EST) Output Circuit Fault
Chart A-1	No "Check Powertrain" Lamp		
Chart A-2	No Serial Data, Will Not Flash DTC 12, Malfunction Indicator Lamp (MIL) "Check Powertrain" Lamp "ON" Steady	DTC 42	V6 PCM - Ignition Bypass Circuit Fault
		DTC 43	V6 PCM - Knock Sensor Circuit Fault
		DTC 44	V6 PCM - Right Hand (RH) Lean Exhaus Indication
Chart A-3.1	V6 PCM - Engine Cranks But Will Not Run		
Chart A-3.2	V6 PCM - Engine Cranks But Will Not Run	DTC 45	V6 PCM - Right Hand (RH) Rich Exhaus Indication
Chart A-3.3	V6 PCM - Engine Cranks But Will Not Run		
Chart A-4.1	V6 PCM - Fuel Pump Electrical Circuit	DTC 46	V6 PCM - No Reference Pulses While Cranking
Chart A-4.2	V6 PCM - Fuel Pump Electrical Circuit		
Chart A-4.3	V6 PCM - Fuel Delivery System	DTC 47	V6 PCM - 18X Reference Signal Missing
Chart A-4.4	V6 PCM - Fuel Delivery System	DTC 48	V6 PCM - Camshaft Position Signal Missing
Chart A-4.5	V6 PCM - Fuel Delivery System		
Chart A-5.2	V6 PCM - Cranking Signal Circuit	DTC 49	V6 PCM - Cam/Crank Signal Intermitten
Chart A-6.1	V6 PCM - MAF Sensor Output Check	DTC 51	V6 PCM - PROM Error
Chart A-6.2	V6 PCM - TP Sensor Output Check	DTC 52	V6 PCM - System Voltage Too High - Long Time
Chart A-6.3	V6 PCM - Oxygen Sensor Check		
Chart A-6.3A	V6 PCM - Oxygen Sensor Heater Check	DTC 53	V6 PCM - System Voltage Too High
Chart A-6.4	V6 PCM - Canister Purge Solenoid Check	DTC 54	V6 PCM - System Voltage Unstable
Chart A-7-1	V6 PCM - Idle Air Control (IAC) System	DTC 55	V6 PCM - PROM - Analog - Digital (A/D) Conversion ErrorA-154
Chart A-7-2	V6 PCM - Idle Air Control (IAC) System		
Chart A-8-1	V6 PCM - Direct Ignition System (DIS) Check	DTC 57	V6 PCM - Injector Voltage Monitor Fault
Chart A-8.2	V6 PCM - Direct Ignition System (DIS) Check	DTC 58	V6 PCM - Transmission Fluid Temperat (TFT) (Signal Voltage Low)
Chart A-11.1	V6 PCM - A/C Clutch Control		
Chart A-11.2	V6 PCM - A/C Clutch Control	DTC 59	V6 PCM - Transmission Fluid Temperat (TFT) (Signal Voltage High)
Chart A-11.3	V6 PCM - A/C Clutch Control with Electronic Climate Control	DTC 63	V6 PCM - Left Hand (LH) NO Oxygen Sensor Signal
Chart A-11.4	V6 PCM - A/C Clutch Control with Electronic Climate Control	DTC 64	V6 PCM - Left Hand (LH) Lean Exhaust Indication
Chart A-12.1	V6 PCM - Electric Fan Control		
Chart A-12.2	V6 PCM - Electric Fan Control	DTC 65	V6 PCM - Left Hand (LH) Rich Exhaust

Chart A-12.3	V6 PCM - Electric Fan Control
Chart A-13	V6 PCM - Restricted Exhaust Check
DTC 13	V6 PCM - Right Hand (RH) No Oxygen Sensor Signal
DTC 14	V6 PCM - Engine Coolant Temperature (ECT) (Signal Voltage Low)
DTC 15	V6 PCM - Engine Coolant Temperature (ECT) (Signal Voltage High)
DTC 16	V6 PCM - Engine Coolant Temperature (ECT) (Signal Voltage Unstable)0
DTC 17	V6 PCM - PCM Error - ECT Circuit
DTC 19	V6 PCM - Throttle Position (TP) Sensor Stuck
DTC 21	V6 PCM - Throttle Position (TP) (Signal Voltage High)

	Indication
DTC 66	V6 PCM - 3-2 Control Solenoid Circuit F
DTC 67	V6 PCM - Torque Converter Clutch "ON OFF" Circuit Fault
DTC 69	V6 PCM - Torque Converter Clutch Stuc "ON"
DTC 72	V6 PCM - Vehicle Speed Signal Intermittent
DTC 73	V6 PCM - Pressure Control Solenoid Current (Current Error)
DTC 75	V6 PCM - System Voltage Low
DTC 76	V6 PCM - Short Term Fuel Trim (STFT) Delta High
DTC 78	V6 PCM - Long Term Fuel Trim (LTFT) Delta High
DTC 79	V6 PCM - Transmission Fluid Temperat (TFT) Too High
DTC 81	V6 PCM - 2-3 Shift Solenoid "B" Circuit Fault
DTC 82	V6 PCM - 1-2 Shift Solenoid "A" Circuit Fault
DTC 83	V6 PCM - Torque Converter Clutch (TCC Solenoid "PWM Circuit Fault
DTC 92	V6 PCM - Low Speed Fan No BCM Response
DTC 93	V6 PCM - SNEF Circuit Fault
DTC 94	V6 PCM - No Vehicle Speed Signal (Manual Transmission)
DTC 97	V6 PCM - Canister Purge Circuit Fault