



NOTE:- CONVENTIONAL CURRENT FLOW IS ASSUMED IE. FLOWING FROM BATTERY +VE TO BATTERY -VE

INTRODUCED DURING OCTOBER 2002



WIRING DIAGRAMS

HARNESS SYMBOLS: (M.W.H.) (BAT.) (P.T.) (B.) (E.C.)

