






























<b>YB35 (POWER TRAIN HARNESS)</b> NEUTRAL START & BACK-UP SWITCH 	<b>YB39 (M.W.H)</b> BODY HARNESS CONNECTOR 	<b>YB41 (M.W.H)</b> HEATED REAR WINDOW RELAY 	<b>YB44 (M.W.H)</b> IGNITION SWITCH 
<b>YB61 (R.H. FRONT DOOR HARNESS)</b> ELECTRIC MIRROR SWITCH 	<b>YB74 (M.W.H)</b> BODY HARNESS CONNECTOR 	<b>YB76 (BODY HARNESS)</b> R.H.FRONT DOOR HARNESS CONNECTOR 	
<b>YB77 (BODY HARNESS)</b> L.H.FRONT DOOR HARNESS CONNECTOR 	<b>YB174 (M.W.H)</b> B.C.M CONNECTOR 2 		
<b>YB176 (M.W.H)</b> B.C.M CONNECTOR 4 		<b>YB220 (POWER SEAT HARNESS)</b> POWER SEAT CONTROL SWITCH CONNECTOR 	
<b>YB221 (POWER SEAT HARNESS)</b> POWER SEAT MOTOR CONNECTOR 	<b>YB222 (POWER SEAT HARNESS)</b> POWER SEAT MOTOR CONNECTOR 	<b>YB223 (POWER SEAT HARNESS)</b> POWER SEAT MOTOR CONNECTOR 	<b>YB224 (POWER SEAT HARNESS)</b> POWER SEAT MOTOR CONNECTOR 
<b>YB225 (POWER SEAT HARNESS)</b> POWER SEAT MODULE CONNECTOR 1 			
<b>YB226 (BODY HARNESS)</b> POWER SEAT HARNESS CONNECTOR 	<b>YB227 (POWER SEAT HARNESS)</b> POWER SEAT MODULE CONNECTOR 2 		
<b>YB228 (POWER SEAT HARNESS)</b> POWER SEAT MODULE CONNECTOR 3 		<b>YB229 (POWER SEAT HARNESS)</b> POWER SEAT MODULE CONNECTOR 4 	
<b>YB235 (POWER SEAT HARNESS)</b> MOTOR POSITION SENSORS 		<b>YB236 (POWER SEAT HARNESS)</b> RECLINE MOTOR POSITION SENSOR 	
<b>YB237 (R.H. FRONT DOOR HARNESS)</b> R.H. ELECTRIC MIRROR MOTOR 		<b>YB238 (R.H. FRONT DOOR HARNESS)</b> MIRROR CONTROL MODULE CONNECTOR 	
<b>YB239 (L.H. FRONT DOOR HARNESS)</b> L.H. ELECTRIC MIRROR MOTOR 	<b>YE112 (POWER TRAIN HARNESS)</b> ENGINE CONNECTOR 3 	<b>YE114 (M.W.H)</b> E3 EARTH LOCATION CONNECTOR 	<b>YR1 (BODY HARNESS)</b> HEATED REAR WINDOW CONNECTOR 
<b>YR53 (BODY HARNESS)</b> BACK -UP LAMP CONNECTOR 			

## WIRING DIAGRAMS

HARNESS SYMBOLS:  (M.W.H.)  (F.D.)  (B.)  (P.T.)  (RR.D.)  (R.L.)

