



NOTE:- CONVENTIONAL CURRENT FLOW IS ASSUMED IE. FLOWING FROM BATTERY +VE TO BATTERY -VE.

WIRING DIAGRAMS

HARNESS SYMBOLS:  (M.W.H.)  (P.T.)  (B.)

